



AirCard® 880 / 881 / 880E / 881E / 875

Wireless Network Card Quick Start Guide




This guide provides installation instructions for users of Windows® Vista™, XP, and 2000.

Your package contains the following:


- AirCard wireless network card (modem)
- Installation CD containing 3G Watcher™ software and Installation Guide
- This Quick Start Guide

1



Please do not insert the AirCard modem into the PC Card / Express Card slot before installing the software.

2




Insert the CD in the CD-ROM drive and the setup process starts automatically. If it does not, select **Start > Run** and enter **d:\Setup.exe**, where **d** is your CD-ROM drive letter, and follow the onscreen instructions.

3


Select the **Notebook software installation** menu option. This launches an installation program that guides you through the installation of Watcher and the AirCard drivers.

4



Insert the SIM / USIM into the AirCard modem, as shown in the illustration.

5



When prompted, insert the AirCard modem into the PC Card / Express Card slot. Watcher automatically launches once you insert the AirCard modem.

The first time you use your AirCard modem., it takes a few minutes to locate the network.

6

Click **Connect**. If you are prompted to configure a profile, click **Yes**. The Connections window opens to the Profiles pane and automatically selects the appropriate profile template. If you want to initiate a connection each time the AirCard modem is inserted, select **Connection type**, and from the drop-down list, select **AutoConnect**. Click **OK**.

The AirCard modem is ready to use.

To access the Help system in Watcher, select **Help > Help topics**.

If you are using Microsoft® Internet Explorer® as your browser, you may need to configure it to use the AirCard modem. (See the Installation Guide on the CD.)